


AB-170P

Exploded



Parts List

NO.5

Index No.	Parts No.	Description	No. Req'd	Index No.	Parts No.	Description	No. Req'd
01	0880079	Screw	4	28	0860016	Bearing	1
02	0800016	Washer	4	29	0890055	End Plate Gasket	1
03	1700109	Clutch Housing	1	30	1700102	Housing Cover	1
04	1700112	Housing Bushing	1	31	0850079	"O"Ring	1
05	0810006	Circlet	1	32	1700106	Reverse Valve	1
06	0850003	"O"Ring	1	33	0820010	Circlet	1
07	1700001	Anvil Shank	1	34	0810081	Spring	1
08	0840078	Pin	2	35	0840171	Pin	1
09	1600005	Hammer Frame	1	36	0840169	Pin	2
10	1600017	Hammer	2				
11	0890051	End Plate Gasket	1				
12	0800113	Washer	1	AB-170P(3/8")			
13	1700101	Motor Housing	1	05	0810013	Circlet	1
14	1610008	Trigger	1	06	0850011	"O"Ring	1
15	0800121	Washer	1	07	1700013	Anvil Shank	1
16	1610007	Throttle Valve	1	AB-170P(1/4")			
17	0810046	Spring	1	05	0810042	Pin	1
18	1900013	Exhaust Deflector	1	06	0800054	Washer	2
19	1900015	Air Strainer	1	07	1700014	Anvil Shank	1
20	0800011	Washer	1	37	1600110	Block Sleeve	1
21	0860008	Bearing	1	38	0810043	Spring	1
22	1700105	Front Plate Gasket	1	39	0870003	Steel Ball	1
23	1700004	Liner	1	AB-170P-1/AB-170P(3/8")-1/AB-170P(1/4")-1			
24	0840150	Pin	1	19	1900024	Air Strainer	1
25	1700008	Vane	6	AB-170P-2/AB-170P(3/8")-2/AB-170P(1/4")-2			
26	1700103	Rotor	1	19	1900020	Air Strainer	1
27	1700104	Rear End Plate	1				

※We reserve the right to make changes to the designs of the parts without prior notice.